

NEW!

BOOMER™ CAB COMPACT TRACTORS 37 TO 47 HP

BOOMER 37 | BOOMER 41 | BOOMER 47



READY FOR ANY JOB

Whether you need to load mulch, mow the lawn, clear a pasture, dig a trench, till the garden, move snow, clean stalls or install a fence, Boomer tractors are for you. These tractors make it easy to change implements so you can move quickly from job to job.



- Comfortable and spacious cab
- Premium controls
- Increased visibility
- Tier 4B emissions compliant
- Category I three-point hitch
- Two optional rear hydraulic remotes
- Independent, electro-hydraulic 540-rpm rear PTO
- Available mid PTO to power mid- and front-mount implements
- Dozens of matching accessories, implements and attachments to match your needs
- 3 range HST or 12x12 SSS on Boomer 37
- 3 range HST or 16x16 SSS transmission on Boomer 41 and 47

BOOMER™ CAB COMPACT TRACTOR SPECIFICATIONS

MODEL		BOOMER 37	BOOMER 41	BOOMER 47
ENGINE				
Gross horsepower	hp (kW)	36.2 (27)	40.2 (30)	45.6 (34)
Rated speed	rpm	2600		
No. of cylinders		3	4	4
Aspiration		Turbo	Natural	Natural
Displacement	cu. in. (L)	91 (1.5)	135 (2.2)	135 (2.2)
Air cleaner		Replaceable dry element		
Fuel tank	gal. (L)	10.5 (40)		
Alternator	amps	85		
PTO				
PTO HP (Gear)	hp (kW)	31.1 (23.2)	31.6 (23.5)	37.3 (27.8)
PTO HP (HST)	hp (kW)	29.2 (21.8)	29.8 (22.1)	35.0 (26.1)
PTO speed	rpm	540		
PTO type		Independent with electro-hydraulic engagement		
Mid-PTO Speed		2000		
TRANSMISSION				
Type, Mechanical / Hydrostatic		12x12 / HST+3 range	16x16 / HST+3 range	16x16 / HST+3 range
Maximum forward speed,				
Gear	mph (kph), R4	14.2 (22.9)	17.0 (27.3)	17.0 (27.3)
HST	mph (kph), R4	14.8 (23.8)	17.9 (28.8)	17.9 (28.8)
Gear/shuttle type		Synchro		
Rear diff. lock engagement		Mechanical		
Brake type		Wet, Multi Disc		
HYDRAULICS				
Implement hydraulic flow	gal. (lpm)	8.2 (31.0)		
Steering hydraulic flow	gal. (lpm)	4.2 (15.9) / 5.3 (19.9) HST		
Remote valves		Optional		
3-point lift capacity @ ball ends	lb. (kg)	1,807 (820)	2,756 (1250)	2,756 (1250)
3-point linkage category		1		
Steering type		Hydrostatic		
DIMENSIONS				
Wheel base	in. (cm)	66 (167.6)	73.2 (186)	73.2 (186)
Length	in. (cm)	119 (302.4)	128.1 (325.4)	128.1 (325.5)
Width	in. (cm)	66.4 (168.7)	69.1 (175.5)	69.1 (175.5)
Height (CAB)	in. (cm)	90 (228.6)	94 (238.76)	95 (238.76)
Weight	lbs. (kg)	3574 (1622)	4194 (1903)	4194 (1903)

SPECIFICATIONS

Platform Type	Semi-Flat
Steering column	Tilt
Heat, air conditioning & cab recirculation	Yes
Front wiper / washer (single speed)	Yes
Left and right hand doors	Yes
Radio ready - includes antenna, wiring, DIN sleeve and 2 speakers	Yes
Safety flashers & turn indicators	Yes
Two front cab work lights	Yes
Two external mirrors	Yes
Interior dome light	Yes
12 volt power source	Yes
Horn	Yes
Opening rear window & side opening windows	Yes
Provision for roof becan (electrical supply)	Yes
Cupholders	Yes
Cloth seat - mechanical suspension	Yes
Retractable seat belt	Yes
Swivel	No

OPTIONS

Sun visor	Opt
Two additional rear work lights	Opt
Rear window wiper / washer	Opt
Roof becan	Opt
Interior rear view mirror	Opt



We've got your back with the FREE Boomer Guard 5 Limited Warranty. It provides 5 years of worry-free operation, including 2 years of bumper-to-bumper coverage plus an extra 3 years of powertrain protection. You won't find a better compact tractor or warranty anywhere.



Learn more at www.newholland.com/na

Design, materials and/or specifications are subject to change without notice and without liability therefor. Specifications are applicable to units sold in Canada, the United States, its territories and possessions, and may vary outside these areas.

© 2015 CNH Industrial America LLC. All rights reserved. New Holland is a trademark registered in the United States and many other countries, owned by or licensed to CNH Industrial N.V., its subsidiaries or affiliates. Any trademarks referred to herein, in association with goods and/or services of companies, other than owned by or licensed to CNH Industrial N.V., its subsidiaries or affiliates, are the property of those respective companies.



Safety begins with a thorough understanding of the equipment. Always make sure you and your operators read the Operator's Manual before using the equipment. Pay close attention to all safety and operating decals and never operate machinery without all shields, protective devices and structures in place.

NH36145328 • 0515XX • XX • PRINTED IN U.S.A.